

Accessories

Extensive, user-friendly Range



MW 1100 / MW 1100S:

- Belt bag
- Charger lead for operation in vehicles

MW 1150:

- Thermoprinter P 1150
- Pt100 temperature sensor
- External infrared temperature sensor
- Connector kit for analog output 4-20 mA
- Hoppers, brushes, dishes
- Spare beakers for beaker sensors



MW 4300 / MW 4310:

- Hoppers, brushes, dishes
- Spare beakers for beaker sensors
- Analog remote display
- PC software TEWS Moisture View ©

MW 4200 / MW 4260 / MW 4270:

- Modem for remote maintenance
- Infrared temperature sensor
- Analog remote display
- Display and control panel
- PC software TEWS Moisture View ©